


PTZ Controls

Created	@July 16, 2025 2:21 PM
Tags	Live View

Step 1

To access the PTZ controls, click on the ">" button to the right of the PTRZ tab in the bottom left corner.



Step 2

The menu will expand upwards. Commonly used controls are detailed in the image below.

