



Wiring Diagrams

Weigand wiring




ST10-MEK Reader

RS-485 wiring



OSDP Reader

REX Connection



Lock Relay Connection

The system supports both **Normally Opened Lock** and **Normally Closed Lock**. The **NO Lock** (Normally Opened when powered) is connected with 'NO' and 'COM' terminals, and the **NC Lock** (Normally Closed when powered) is connected with 'NC' and 'COM' terminals. As shown in the example with NC Lock below.

