


Configuration - Installation

🕒 Created	@January 5, 2026 8:51 AM
☰ Tags	



Server Installation Guide


X-VMS Server and client software are both currently (1/5/2026) Windows only.

The installer file can be found on the LTS website's download page.




The downloaded file will be a zip file with the Server installer inside, the client installer can be downloaded from the X-VMS Server **AFTER** the installation is finished. Extract X-VMS server install file from the zip and then run the installer.







After installation, when you login to the server through a browser, it will ask to setup password reset.



Verification Code is through email. Setup all the email information to receive a code if a password reset is required.




The second option is to use security questions. Only 1 question is required.




Client Installation Guide

The installer file for the X-VMS client is available after installing the server software AND activating with a license.



Run the installer.



There will be multiple UAC requests while installing.