


# Control Client - Monitoring



🕒 Created	@January 23, 2026 9:59 AM
☰ Tags	

## Live View/Monitoring


In the control panel, click on “Monitoring”. Entering “Monitoring” will bring the client into the area where cameras and doors can be viewed.




Click and drag the cameras into the main area to load up live views.




Mousing over the live view of cameras will bring up some buttons at the bottom section of the live view. These shortcuts are options such as: PTZ Control, Stream Selection, Digital Zoom, etc.




Clicking "Playback" at the top will begin playback. The cameras that were already loaded into Live View will be the ones that will begin playback, depending on the number of cameras already in live view, this can cause some slow downs in the client.




The timeline at the bottom can be scrubbed through to playback at different times.



Clicking on the Calendar icon at the bottom will bring up a selectable calendar menu if there is a need to move to a specific date for playback.



There are some other options available at the bottom separate from these, which are standard /playback options such as: Play, Pause, Slow Forward, Fast Forward, etc.



The button for "Synchronous Playback" will alternate between synced playback or unsynced playback.



To the right of the timeline, there are 2 buttons for zooming in/out of the timeline when scrubbing needs to be more precise.



